

## SCHOEPS CAPSULE SWIVEL GVC



The electrically passive GVC capsule swivel may be inserted between any capsule and microphone amplifier of the Colette modular system, or before an Active Cable, Active Extension Tube, or the CUT 1.

**Cena:**

**Kategorie:** [Audio](#), [Mikrofony](#)





*AF 1 above the table surface*



*AF 1 beneath the table surface*

## GALLERY IMAGES



## OPIS

- allows the angle of a capsule to be adjusted on all microphone amplifiers of the Colette modular system
- adjustable from 0° through 120° in either direction

### **Application**

The GVC is especially useful with capsules intended for frontal sound pickup such as the MK 4 (cardioid). Laterally-addressed capsules (MK 4V, MK 41V, MK 4VXS, MK 6 and MK 8) can be used on the GVC with a small elastic ring which we will supply at no extra charge. This ring should be slipped over the threads of the GVC so that the capsule can be aimed in the desired direction.

Furthermore, the GVC is often used on a boom for film sound recording, since with its use, an MK 41 supercardioid on a CMC 6 amplifier can be used very close to the ceiling while aiming downward. The typical usage as part of a built-in table microphone can be seen below.